

How to encrypt my wireless network?

It is suitable for : **N100RE, N150RH, N150RT, N151RT, N200RE, N210RE, N300RT, N300RH, N300RH, N300RU, N301RT, N302R Plus, N600R, A702R, A850, A800R, A810R, A3002RU, A3100R, T10, A950RG, A3000RU**

Application introduction: TOTOLINK router provided repeater function, with this function users can expand the wireless coverage and allow more terminals to access Internet.

Set a encrypted wireless network, please following these steps.

STEP-1:

Connect your computer to the router by cable or wireless, then login the router by entering http://192.168.0.1 into the address bar of your browser.



Note:

The default access address varies depending on the actual situation. Please find it on the bottom label of the product.

STEP-2:

User Name and Password are required, by default both are **admin** in lowercase letter. Click **LOGIN**.

USER LOGIN

Forget Password?

User Name

Password

STEP-3:

Click Wireless Settings->Wireless Setup on the left menu.



STEP-4:

In this interface, you can encrypt your network now.

Basic Settings

Basic Settings Enabled ▾

SSID

Broadcast SSID Enabled ▾

Encryption WPA2 ▾

Limit Client AP(3-64)

Download: Mbps (0:Unlimit)

Upload: Mbps (0:Unlimit)

Authentication Mode
 Enterprise (RADIUS)
 Personal (Pre-Shared Key)

WPA2 Cipher Suite
 TKIP
 AES

Pre-Shared Key Format Passphrase ▾

Pre-Shared Key

WEP-Open System, WEP-Shared Key, WPA-PSK, WPA2-PSK and WPA/WPA2-PSK are provided for your, for better security, WPA/WPA2-PSK is recommended.

