How to use wireless schedule?

It is suitable for： **N600R, A800R, A810R, A3100R, T10, A950RG, A3000RU**

Application introduction:

This router has a built-in real time clock which can update itself manually or automatically by means of Network Time Protocol (NTP). As a result, you can schedule the router to dialup to the Internet at a specified time, so that users can connect to the Internet only during certain hours.

STEP-1:

Please login to the web-configuration Interface of the router.

STEP-2: Check Time Setting

Before using schedule function you have to set your time correctly.

2-1. Click **Management->Time Setting** in the sidebar.



2-2. Enable NTP client update and choose the SNTP server, click Apply.



STEP-3: Wireless Schedule Setup

3-1. Click Management->Wireless Schedule



3-2. Enable the schedule at first, in this section, you can setup the specify time so the WiFi will be on during this period. The picture is a example, and WiFi will be on from eight o' clock to eighteen o'clock on Sunday.