

How to setup Smart QoS?

It is suitable for: **A1004, A2004NS, A5004NS, A6004NS**

Application:

When there are too many PCs in LAN, it is difficult to set speed limit rules for every computer. You can use smart QoS function to assign equal bandwidth for each PC.

STEP-1: Connect your computer to the router

1-1. Connect your computer to the router by cable or wireless, then login the router by entering <http://192.168.1.1> into the address bar of your browser.



Note:


The default access address varies depending on the actual situation. Please find it on the bottom label of the product.



1-2. Please click Setup Tool to enter the router's setting interface.




1-3. Please login to the Web Setup interface (the default user name and password is admin).




STEP-2: Enable Smart QoS

(1). Click **Advanced Setup->Traffic->QoS setup.**



(2). Select Start, then Input Download Speed and Upload Speed, then Click Apply.



Or you can fill in **IP Address** and **Down** and **Up Speed** you want to restrain, then Click **Apply**.

